ASSEMBLY AND INSTALLATION INSTRUCTIONS

W0019


WARNING: BE SURE TO SHUT OFF POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE INSTALLING OR SERVICING THIS FIXTURE.

NOTE: 1. Before installing, consult local electrical codes for wiring and grounding requirements.

House Grounding Wire-Green Grounding Screw

Headless Screw

2. READ AND SAVE THESE INSTRUCTIONS.



Fixture Wire

Mounting Screw

Fixture Grounding Wire

Rubber Pad

Particular Socket

Socket

Glass Shade

Bulb Type G Max.60 W

(Not included)

Frame

 Thread two headless screws to the mounting plate, and secure them with four lock nuts (two on each side of the mounting plate).
 Adjust the length of the headless screws if necessary.

Note: Make sure that the headless screws are lined up horizontally, to ensure that the fixture will be level.

- 2. Attach the mounting plate to the outlet box by using two mounting screws.
- 3. Pull out the outlet wires and the house grounding wire from the outlet box. Make wire connections using the wire nuts:
 - ---Connect the black wire from the fixture to the black wire from the power source.
 - ---Connect the white wire from the fixture to the white wire from the power source.
 - ---Attach the fixture grounding wire to the mounting plate with the green grounding screw. Then connect it to the house grounding wire with a wire nut.

Carefully put the wires back into the outlet box.

- 4. Attach the back plate to the mounting plate by inserting the headless screws, then secure it with two rubber pads and ball nuts(-b).
 - CAUTION: With silicone caulking compound, caulk completely around where the back plate meets with the wall surface to prevent water from seeping into the outlet box.
- 5. Attach the glass shades and frames onto the fixture, secure it with the rubber pads and ball nuts(-b).
- 6. Install bulbs (not included). See relamping label at socket area or packaging for maximum allowed wattage.
- 7. Turn on the power at the main fuse or circuit breaker box.



Outlet Box

Wire Nut

Mounting Plate

Lock Nut

Back Plate

Rubber Pad

Ball Nut(-b)

Fixture